


































































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV / R	 TV/R
 Home	 Smart
 FAV	 Pre Ch
 Back	 Back
 Audio	 Dual

Originale	Sostituto
 Info	 Info
 EPG	 Guide
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Menu	 Menu
 Exit	 Exit
 Vol +	 Vol +
 Vol -	 Vol -
 P +	 Shift + Ch +
 List	 List
 P -	 Shift + Ch -
 CH +	 Ch +
 CH -	 Ch -
 OPT	 Options





Originale		Sostituto	
	Text		Text
	SUB		Subt
	Message		Format
	Pause		Pause
	<<		<<
	>>		>>
	Rec		Rec
	Play		Play
	I<<		I<<
	>>I		>>I
	Stop		Stop
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Originale	Sostituto

