



Originale		Sostituto		Originale		Sostituto	
	Standby		Power		Menu		Menu / Home
	Mute		Mute / Dimmer		EPG		Guide / EPG / -/-
	1		1		Exit		Exit / Cancel / Clear
	2		2		Up		Up
	3		3		CH+		CH+ / Page+
	4		4		Left		Left
	5		5		Vol-		Vol-
	6		6		OK		OK
	7		7		Right		Right
	8		8		Vol+		Vol+
	9		9		Down		Down
	FAV		Fav / Marker / PC		CH-		CH- / Page-
	0		0		Text		Text / Goto
	Recall		Back / Return		Red		Red / Netflix / Search
	Audio		Audio / Lang / I/I		Green		Green / APP / Repeat
	Subtitle		Subtitle / EQ		Pause		Pause / Step / Freeze
	Info		Info / Angle		Tv/Radio		TV/Radio /





Originale		Sostituto		Originale		Sostituto	
	Yellow	 REPEAT A-B	Yellow / YouTube / Repeat				
	Blue	 RANDOM	Blue / Prime Video / Random				

