





























































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Display		Info
	Mute		Mute		Sleep		Sleep
	1		1		Vol+		Vol +
	2		2		Vol-		Vol -
	3		3		CH+		Ch +
	4		4		CH-		Ch -
	5		5		FAV/List		Shift + Pre Ch
	6		6		Clock		Shift + AV
	7		7		List		List
	8		8		Tv/Radio		TV/R
	9		9		Aspect		Format
	0		0		Freeze		Pause
	-/--		Guide		Index		Options
	Recall		Pre Ch		Cancel		Back
	Menu		Menu		Subpage		Subt
	Source		AV		Text		Text
	Exit		Exit		Size		Eject





	Originale	Sostituto
	Reveal	Media
	Hold	Dual
	Mix	+ Shift + Media
	Red	Red
	Green	Green
	Yellow	Yellow
	Cyan	Blue
	Nicam	Smart
	P.Mode	+ Shift + Format
	S.Mode	+ Shift + Dual
	OK	Ok
	Up	Up
	Down	Down
	Right	Right
	Left	Left

Originale	Sostituto

