







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		9		9
	CH.List		List		0		0
	Tv/Radio		TV/R		Info		Info
	FAV		Pre Ch		Recall		Back
	Sleep		Sleep		Freeze		Pause
	Input		AV		Guide		Guide
	Sound		Shift + Dual		I/II/Audio Lang		Dual
	Picture		Shift + Format		Vol+		Vol +
	Aspect		3D		Vol-		Vol -
	1		1		Mute		Mute
	2		2		Prog+		Ch +
	3		3		Prog/Page-		Ch -
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok



