































Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Source	 AV
 Guide	 Guide
 Menu	 Menu
 Exit	 Exit
 Option	 Options
 Return	 Back

Originale	Sostituto
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Smart Tv	 Smart
 You Tube	 Media
 CH+	 Ch +
 CH-	 Ch -
 Text	 Text
 Subtitle	 Subt
 List	 List
 Info	 Info
 O)/Lang	 Dual



