




































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Text	 Text
 Subtitle	 Subt
 List	 List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Recall	 3D
	 Back

Originale	Sostituto
 Menu	 Menu
 Source	 AV
 Exit	 Exit
 Info	 Info
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 Ok
 Smart Tv	 Smart
 YouTube	 Media
 Netflix	 Shift + Media
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red	 Red





Originale		Sostituto		Originale	Sostituto
	Green		Green		
	Yellow		Yellow		
	Blue/O)/Lang		Blue		
	P.Mode		Format		
	S.Mode		Dual		
	Sleep		Sleep		
	Guide		Guide		
	FAV		Pre Ch		
	Option		Options		
	<<		<<		
	>>		>>		
	I<		I<<		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	>I		>>I		

