





























































































Originale	Sostituto	Originale	Sostituto
 Power TV	 Power	 Test	 Text
 Home Theater	 Media	 Delay	 Format
 Home Theater	 Smart	 Level	 3D
 Tape	 Red	 -	 Ch -
 CD	 Yellow	 +	 Ch +
 Tuner/Band	 Green	 1 Tv	 1
 DVD	 Blue	 2 Tv	 2
 Up	 Up	 3 Tv	 3
 Left	 Left	 4 Tv	 4
 Select	 Ok	 5 Tv	 5
 Right	 Right	 6 Tv	 6
 Down	 Down	 7 Tv	 7
 Display	 Info	 8 Tv	 8
 Menu	 Menu	 9 Tv	 9
 Stereo	 Dual	 0 Tv	 0
 Surround	 Subt	 >10 Tv	 Guide
 SFC	 Options	 CH-	 Shift + Ch -
















Originale		Sostituto		Originale		Sostituto	
	Power DVD		Power		Menu		Menu
	Home Theater		Media		Stereo		Dual
	Home Theater		Smart		Surround		Subt
	Tape		Red		SFC		Options
	CD		Yellow		Test		Text
	Tuner/Band		Green		Delay		Format
	DVD		Blue		Level		3D
	Play DVD		Play		-		Ch -
	I<</<< DVD		<<		+		Ch +
	Stop DVD		Stop		1 DVD		1
	>>/>>I DVD		>>		2 DVD		2
	Up		Up		3 DVD		3
	Left		Left		4 DVD		4
	Select		Ok		5 DVD		5
	Right		Right		6 DVD		6
	Down		Down		7 DVD		7
	Display		Info		8 DVD		8
















Originale	Sostituto
 Power CD	 Power
 Power Tape	 +  Shift + Power
 Home Theater	 Media
 Home Theater	 Smart
 Tape	 Red
 CD	 Yellow
 Tuner/Band	 Green
 DVD	 Blue
 Play Tape	 +  Shift + Play
 Play CD	 Play
 I<</<< Tape	 +  Shift + <<
 I<</<< CD	 <<
 Stop Tape	 +  Shift + Stop
 Stop CD	 Stop
 >>/>>I Tape	 +  Shift + >>
 >>/>>I CD	 >>
 Up	 Up

Originale	Sostituto
 Left	 Left
 Select	 Ok
 Right	 Right
 Down	 Down
 Display	 Info
 Menu	 Menu
 Stereo	 Dual
 Surround	 Subt
 SFC	 Options
 Test	 Text
 Delay	 Format
 Level	 3D
 -	 Ch -
 +	 Ch +
 Direct Tuning/Disc Enter	 D. Menu
 1 CD-Tape	 1
 2 CD-Tape	 2





Originale	Sostituto
 Power VCR	 Power
 Power Tuner/Band	 +  Shift + Power
 Home Theater	 Media
 Home Theater	 Smart
 Tape	 Red
 CD	 Yellow
 Tuner/Band	 Green
 DVD	 Blue
 Play	 Play
 I<</<<	 <<
 Stop	 Stop
 >>/>>I	 >>
 Up	 Up
 Left	 Left
 Select	 Ok
 Right	 Right
 Down	 Down

Originale	Sostituto
 Display	 Info
 Menu	 Menu
 Stereo	 Dual
 Surround	 Subt
 SFC	 Options
 Test	 Text
 Delay	 Format
 Level	 3D
 -	 Ch -
 +	 Ch +
 Direct Tuning/Disc Enter	 D. Menu
 1 VCR	 1
 1 Tuner/Band	 +  Shift + 1
 2 VCR	 2
 >10 VCR	 Guide
 2 Tuner/Band	 +  Shift + 2
 3 VCR	 3



