








































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Recall	 Back
 Mute	 Mute	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 EPG	 Guide
 3	 3	 P+	 Ch +
 4	 4	 P-	 Ch -
 5	 5	 Red	 Red
 6	 6	 Green	 Green
 7	 7	 Yellow	 Yellow
 8	 8	 Blue	 Blue
 9	 9	 Menu	 Menu
 0	 0	 Back	 Pre Ch
 Photo/Video/Music	 Options	 i	 Info
 Internet	 Smart	 Exit	 Exit
 Text	 Text	 Up	 Up
 Subt.	 Subt	 Down	 Down
 Audio	 Dual	 Right	 Right

Originale	Sostituto	Originale	Sostituto
 Recall	 Back	 Red	 Red
 Vol+	 Vol +	 Green	 Green
 Vol-	 Vol -	 Yellow	 Yellow
 EPG	 Guide	 Blue	 Blue
 P+	 Ch +	 Menu	 Menu
 P-	 Ch -	 Back	 Pre Ch
 Red	 Red	 i	 Info
 Green	 Green	 Exit	 Exit
 Yellow	 Yellow	 Up	 Up
 Blue	 Blue	 Down	 Down
 Menu	 Menu	 Right	 Right
 Back	 Pre Ch		
 i	 Info		
 Exit	 Exit		
 Up	 Up		
 Down	 Down		
 Right	 Right		



