

























































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 V-	 Vol -
 Source	 AV	 P+	 Ch +
 1	 1	 P-	 Ch -
 2	 2	 [G]	 Guide
 3	 3	 i	 Info
 4	 4	 Back	 Back
 5	 5	 Exit	 Exit
 6	 6	 OK	 Ok
 7	 7	 Up	 Up
 8	 8	 Down	 Down
 9	 9	 Right	 Right
 0	 0	 Left	 Left
 TXT	 Text	 Netflix	 Media
 Lang	 Dual	 YouTube	 Smart
 Mute	 Mute	 Prime Video	 Shift + Smart
 Home	 Menu	 *1	 Format
 V+	 Vol +	 Red	 Red

Originale	Sostituto	Originale	Sostituto
 V-	 Vol -	 P+	 Ch +
 P-	 Ch -	 [G]	 Guide
 i	 Info	 Back	 Back
 Exit	 Exit	 OK	 Ok
 Up	 Up	 Down	 Down
 Right	 Right	 Left	 Left
 Netflix	 Media	 YouTube	 Smart
 Prime Video	 Shift + Smart	 *1	 Format
 Red	 Red		





Originale		Sostituto		Originale		Sostituto	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec		Rec				
	Play		Play				
	Stop		Stop				

