






























































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 V.Select	 Options
 Mute	 Mute	 Bookmark	 Smart
 Open/Close	 Eject	 Subtitle	 Subt
 1	 1	 A-B	 Text
 2	 2	 Play Mode	 Yellow
 3	 3	 Audio/FM ST	 Dual
 4	 4	 Zoom/Clear	 Format
 5	 5	 Angle/PBC	 3D
 6	 6	 Title/Rotate	 List
 7	 7	 I<<	 I<<
 8	 8	 >>I	 >>I
 9	 9	 <<	 <<
 0	 0	 >>	 >>
 Goto	 Guide	 Stop	 Stop
 Info	 Info	 Play	 Play
 Vol+	 Vol +	 Pause	 Pause
 Vol-	 Vol -	 Up	 Up





	Originale	Sostituto	Originale	Sostituto
	Down			
	Right			
	Left			
	OK			
	AUX/TV/FM			
	DVD			
	EX Bass			
	Menu			
	Surround			
	Sleep			
	Tone			
	Setup/Exit	