
















































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Left/Zoom-		Left
	PIP		3D		OK		Ok
	Swap		Pre Ch		Text		Text
	Sleep		Sleep		Vol+		Vol +
	Freeze		TV/R		Vol-		Vol -
	Zoom		Eject		Mute		Mute
	PIP+		>>I		Return		Back
	PIP-		I<<		PR+		Ch +
	Red/Presets		Red		PR-		Ch -
	Green/List		Green		1		1
	Yellow/Info		Yellow		2		2
	Blue/Guide		Blue		3		3
	Exit		Exit		4		4
	Menu		Menu		5		5
	Up		Up		6		6
	Down		Down		7		7
	Right/Zoom+		Right		8		8









































































	Originale	Sostituto	Originale	Sostituto
	9			
	0			
	AV			
	<<			
	Demo			
	Play			
	>>			
	Rec			
	Stop			
	Pause			








Originale		Sostituto		Originale		Sostituto	
	Power		Power		PR+		Ch +
	Red/Presets		Red		PR-		Ch -
	Green/List		Green		1		1
	Yellow/Info		Yellow		2		2
	Blue/Guide		Blue		3		3
	Exit		Exit		4		4
	Menu		Menu		5		5
	Text		Text		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0
	OK		Ok		AV		AV
	Vol+ Tv		Vol +		<<		<<
	Vol- Tv		Vol -		Play		Play
	Mute		Mute		>>		>>
	Return		Back		Rec		Rec









































































	Originale	Sostituto	Originale	Sostituto
	Stop			
	Pause			
























Originale		Sostituto		Originale		Sostituto	
	Power		Power		Right		Right
	PIP		3D		Left		Left
	Swap		Pre Ch		OK		Ok
	Sleep		Sleep		Vol+ Tv		Vol +
	Freeze		TV/R		Vol- Tv		Vol -
	Zoom		Eject		Mute		Mute
	PIP+		>>I		Return		Back
	PIP-		I<<		PR+		Ch +
	Red/Presets		Red		PR-		Ch -
	Green/List		Green		1		1
	Yellow/Info		Yellow		2		2
	Blue/Guide		Blue		3		3
	Exit		Exit		4		4
	Menu		Menu		5		5
	Text		Text		6		6
	Up		Up		7		7
	Down		Down		8		8









































































Originale		Sostituto		Originale		Sostituto	
	9		9				
	0		0				
	AV		AV				
	Demo		Smart				
	<<		<<				
	Play		Play				
	>>		>>				
	Rec		Rec				
	Stop		Stop				
	Pause		Pause				





Originale		Sostituto		Originale		Sostituto	
	Power		Power		PR-		Ch -
	Red/Presets		Red		1		1
	Yellow/Info		Yellow		2		2
	Blue/Guide		Blue		3		3
	Exit		Exit		4		4
	Menu		Menu		5		5
	Text		Text		6		6
	Up		Up		7		7
	Down		Down		8		8
	Right		Right		9		9
	Left		Left		0		0
	OK		Ok		AV		AV
	Vol+		Vol +		<<		<<
	Vol-		Vol -		Play		Play
	Mute		Mute		>>		>>
	Return		Back		Rec		Rec
	PR+		Ch +		Stop		Stop



