

































Originale	Sostituto
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Return	 Back
 PR+	 Ch +
 PR-	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 OK	 Ok
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green

Originale	Sostituto
 Yellow	 Yellow
 Info	 Info
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Stop	 Stop






Originale		Sostituto		Originale		Sostituto	
	Rec		Rec				
	Pause		Pause				
	Play		Play				
	<<		<<				
	>>		>>				
	ZZZ/List		List				
	Guide		Guide				
	Zoom+		>>				
	Zoom-		<<				













Originale	Sostituto	Originale	Sostituto
Power	Power	Info	Info
Vol+	Vol +	Yellow	Yellow
Vol-	Vol -	Blue	Blue
Mute	Mute	Violet	Media
Return	Back	Text	Text
PR+	Ch +	1	1
PR-	Ch -	2	2
Menu	Menu	3	3
Exit	Exit	4	4
OK	Ok	5	5
Up	Up	6	6
Down	Down	7	7
Right	Right	8	8
Left	Left	9	9
Red	Red	0/--	0
Presets	Dual	AV	AV
Green	Green	Play	Play

Originale	Sostituto	Originale	Sostituto
Info	Info	Info	Info
Yellow	Yellow	Yellow	Yellow
Blue	Blue	Blue	Blue
Violet	Media	Text	Text
Text	Text	1	1
1	1	2	2
2	2	3	3
3	3	4	4
4	4	5	5
5	5	6	6
6	6	7	7
7	7	8	8
8	8	9	9
9	9	0/--	0
0/--	0	AV	AV
AV	AV	Play	Play

































	Originale	Sostituto	Originale	Sostituto
	Stop			
	Pause			
	Rec			
	<<			
	>>			
	Zoom+			
	Zoom-			
	Zzz/List			
	Guide			







Originale	Sostituto
 Power	 Power
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 PR+	 Ch +
 PR-	 Ch -
 Return	 Back
 Exit	 Exit
 Menu	 Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Red	 Red
 Presets	 Dual
 Green	 Green

Originale	Sostituto
 Info	 Info
 Yellow	 Yellow
 Blue	 Blue
 Violet	 Media
 Text	 Text
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/--	 0
 AV	 AV
 Rec	 Rec



