








































| Originale | Sostituto |
|-----------|-----------|
| Power TV | Power |
| 1 TV | 1 |
| 2 TV | 2 |
| 3 TV | 3 |
| 4 TV | 4 |
| 5 TV | 5 |
| 6 TV | 6 |
| 7 TV | 7 |
| 8 TV | 8 |
| 9 TV | 9 |
| 0/-- TV | 0 |
| AV TV | AV |
| Vol+ | Vol + |
| Vol- | Vol - |
| Mute | Mute |
| Return TV | Back |
| PR+ TV | Ch + |

| Originale | Sostituto |
|----------------|-----------|
| PR- TV | Ch - |
| Play TV | Play |
| << TV | << |
| >> TV | >> |
| Record TV | Rec |
| Stop TV | Stop |
| Pause TV | Pause |
| Exit TV | Exit |
| Menu TV | Menu |
| Violet/Text TV | Text |
| Red/Presets TV | Red |
| Green/List TV | Green |
| Yellow/Info TV | Yellow |
| Blue/Guide TV | Blue |
| Up TV | Up |
| Down TV | Down |
| Right/Zoom+ | Right |










































































| Originale | Sostituto |
|---|--|
|  Left/Zoom- TV |  Left |
|  OK TV |  Ok |
|  TV |  TV/R |
|  Demo TV |  Pre Ch |
|  VCR |  Smart |
|  SAT |  Media |
|  DVD |  Options |
|  AUX |  Format |
|  AMP |  3D |
|  Power AUX |  Shift + Power |
|  Red/Presets |  Shift + Red |
|  Green/List AUX |  Shift + Green |
|  Yellow/Info AUX |  Shift + Yellow |
|  Blue/Guide AUX |  Shift + Blue |
|  Up AUX |  Shift + Up |
|  OK AUX |  Shift + Ok |
|  Down AUX |  Shift + Down |


| Originale | Sostituto |
|---|---|
|  Right/Zoom+ |  Shift + Right |
|  Left/Zoom- AUX |  Shift + Left |
|  Exit AUX |  Shift + Exit |
|  Menu AUX |  Shift + Menu |
|  Violet/Text AUX |  Shift + Text |
|  Return AUX |  Shift + Back |
|  PR+ AUX |  Shift + Ch + |
|  PR- AUX |  Shift + Ch - |
|  1 AUX |  Shift + 1 |
|  2 AUX |  Shift + 2 |
|  3 AUX |  Shift + 3 |
|  4 AUX |  Shift + 4 |
|  5 AUX |  Shift + 5 |
|  6 AUX |  Shift + 6 |
|  7 AUX |  Shift + 7 |
|  8 AUX |  Shift + 8 |
|  9 AUX |  Shift + 9 |







































| Originale | | Sostituto | | Originale | | Sostituto | |
|---|-----------------|---|--------|---|----------|---|--------|
|  | Power DVD |  | Power |  | PR+ DVD |  | Ch + |
|  | Red/Presets |  | Red |  | PR- DVD |  | Ch - |
|  | Green/List DVD |  | Green |  | 1 DVD |  | 1 |
|  | Yellow/Info DVD |  | Yellow |  | 2 DVD |  | 2 |
|  | Blue/Guide DVD |  | Blue |  | 3 DVD |  | 3 |
|  | Violet/Text DVD |  | Text |  | 4 DVD |  | 4 |
|  | Up DVD |  | Up |  | 5 DVD |  | 5 |
|  | Down DVD |  | Down |  | 6 DVD |  | 6 |
|  | Right/Zoom+ |  | Right |  | 7 DVD |  | 7 |
|  | Left/Zoom- DVD |  | Left |  | 8 DVD |  | 8 |
|  | OK DVD |  | Ok |  | 9 DVD |  | 9 |
|  | Exit DVD |  | Exit |  | 0 DVD |  | 0 |
|  | Menu DVD |  | Menu |  | AV DVD |  | AV |
|  | Vol+ |  | Vol + |  | Demo DVD |  | Pre Ch |
|  | Vol- |  | Vol - |  | Play DVD |  | Play |
|  | Mute |  | Mute |  | << DVD |  | << |
|  | Return DVD |  | Back |  | >> DVD |  | >> |


























































| Originale | Sostituto |
|---|--|
|  Record DVD |  Rec |
|  Stop DVD |  Stop |
|  Pause |  Pause |
|  TV |  TV/R |
|  VCR |  Smart |
|  SAT |  Media |
|  DVD |  Options |
|  AUX |  Format |
|  AMP |  3D |
|  Power VCR |  Shift + Power |
|  Red/Presets |  Shift + Red |
|  Green/List VCR |  Shift + Green |
|  Yellow/Info VCR |  Shift + Yellow |
|  Blue/Guide VCR |  Shift + Blue |
|  Violet/Text VCR |  Shift + Text |
|  Exit VCR |  Shift + Exit |
|  Menu VCR |  Shift + Menu |


| Originale | Sostituto |
|--|---|
|  Up VCR |  Shift + Up |
|  Down VCR |  Shift + Down |
|  Right/Zoom+ |  Shift + Right |
|  Left/Zoom- VCR |  Shift + Left |
|  OK VCR |  Shift + Ok |
|  Return VCR |  Shift + Back |
|  PR+ VCR |  Shift + Ch + |
|  PR- VCR |  Shift + Ch - |
|  1 VCR |  Shift + 1 |
|  2 VCR |  Shift + 2 |
|  3 VCR |  Shift + 3 |
|  4 VCR |  Shift + 4 |
|  5 VCR |  Shift + 5 |
|  6 VCR |  Shift + 6 |
|  7 VCR |  Shift + 7 |
|  8 VCR |  Shift + 8 |
|  9 VCR |  Shift + 9 |





| Originale | Sostituto | Originale | Sostituto |
|---|-------------|---|-----------|
|  | Power |  | Power |
|  | TV |  | TV/R |
|  | VCR |  | Smart |
|  | SAT |  | Media |
|  | DVD |  | Options |
|  | AUX |  | Format |
|  | AMP |  | 3D |
|  | Red/Presets |  | Red |
|  | Green/List |  | Green |
|  | Yellow/Info |  | Yellow |
|  | Blue/Guide |  | Blue |
|  | Violet/Text |  | Text |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right/Zoom+ |  | Right |
|  | Left/Zoom- |  | Left |
|  | OK |  | Ok |
|  | Exit |  | Exit |
|  | Menu |  | Menu |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | Return |  | Back |
|  | PR+ |  | Ch + |
|  | PR- |  | Ch - |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |





| Originale | Sostituto |
|---|---|
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |

| Originale | Sostituto |
|---|---|
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |
|  |  |



