




































Originale	Sostituto
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >> / Preset+
 <<	 << / Preset-
 PR-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search

Originale	Sostituto
 Sound	 Sound / Title
 Green	 Green / APP / Repeat
 List	 Shift + Smart / List
 Yellow	 Yellow / YouTube / Repeat
 Info	 Info / Angle
 Mosaic	 Smart / List
 Blue	 Blue / Prime Video / Random
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8







Originale	Sostituto	Originale	Sostituto
9	9		
0 / - / -	0		
AV	AV / Input / RDS		
PIP	Zoom / Size		
<< / Pat-Mix	<< / Tune-		
Play / ?	Play / Slow		
>>	>> / Tune+		
Rec / 100	Rec / Rec Mode		
Stop	Stop / Hold		
Pause / - / - / -	Pause / Step / Freeze		
Swap PIP	Setup / OPT /		
Size PIP	Picture / Format		
Position PIP	TV / Radio /		

Originale	Sostituto	Originale	Sostituto







































Originale	Sostituto
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >> / Preset+
 PR-	 CH- / Page-
 <<	 << / Preset-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search

Originale	Sostituto
 Sound	 Sound / Title
 Green	 Green / APP / Repeat
 List	 Shift + Smart / List
 Info	 Info / Angle
 Yellow	 Yellow / YouTube / Repeat
 Mosaic	 Smart / List
 Blue	 Blue / Prime Video / Random
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8






























Originale	Sostituto
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >> / Preset+
 <<	 << / Preset-
 PR-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search

Originale	Sostituto
 Sound	 Sound / Title
 List	 Shift + Smart / List
 Green	 Green / APP / Repeat
 Info	 Info / Angle
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Mosaic	 Smart / List
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8





Originale	Sostituto	Originale	Sostituto
 9	 9		
 0/-/-	 0		
 AV	 RDS AV INPUT		AV / Input / RDS
 PIP	 ZOOM		Zoom / Size
 <</Pat-Mix	 TUNE- ◀		<< / Tune-
 Play/?	 SLOW ▶		Play / Slow
 >>	 TUNE+ ▶▶		>> / Tune+
 Rec/100	 REC MODE ●		Rec / Rec Mode
 Stop	 HOLD ■		Stop / Hold
 Pause/----	 STEP-FREEZE 		Pause / Step / Freeze
 Size PIP	 FORMAT PICTURE		Picture / Format
 Position PIP	 PROGRAM TV/ RADIO		TV/Radio /

