


































































































Originale	Sostituto	Originale	Sostituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source		AV
	ATV/DTV/Content Menu		Smart
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -

Originale	Sostituto	Originale	Sostituto
	Mute		Mute
	Guide/Top		Media
	Exit/Return		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Menu/DVD		Menu
	Tv/FAV/Radio/Set		TV/R
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	[<>]		Format
	←[/]→		3D
	Subtitle		Subt













































































































Originale		Sostituto		Originale		Sostituto	
	←[/]→		3D		Menu/DVD		Menu
	Power		Power		Tv/FAV/Radio/Set		TV/R
	1		1		Guide/Top		Guide
	2		2		[<>]		Format
	3		3		Text		Text
	4		4		Subtitle		Subt
	5		5		O)/II		Dual
	6		6		[i+]/[≡i]		Info
	7		7		OK		Ok
	8		8		Up		Up
	9		9		Down		Down
	0		0		Right		Right
	Source		AV		Left		Left
	Mute		Mute		II/II>/[▼]		Pause
	Vol+		Vol +		Play/[≡o]		Play
	Vol-		Vol -		Stop		Stop
	Exit/Return		Exit		Eject		Eject





Originale	Sostituto	Originale	Sostituto
 Power	 Power	 P-	 Ch -
 ←[/]→	 3D	 Mute	 Mute
 1	 1	 Guide/Top	 Guide
 2	 2	 Exit/Return	 Exit
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 OK	 Ok
 8	 8	 Menu/DVD	 Menu
 9	 9	 Tv/FAV/Radio/Set	 TV/R
 0	 0	 Red	 Red
 Source	 AV	 Green	 Green
 ATV/DTV/Content Menu	 Smart	 Yellow	 Yellow
 Vol+	 Vol +	 Blue	 Blue
 Vol-	 Vol -	 Text	 Text
 P+	 Ch +	 [<>]	 Format

Originale	Sostituto	Originale	Sostituto
 MUTE	 SHIFT	 TV	 DVD
 TV	 DVD	 SAT	 AUX
 PLAY MODE	 REC MODE	 <<<	
 <<<		 ■	 ●
 ■	 ●	 >>>	 >>>
 >>>	 >>>	 DISC NAV	 SOUND
 DISC NAV	 SOUND	 AD	 SETTINGS
 SOUND	 AD	 LIST	 DUAL
 LIST	 DUAL	 SUBT	 OPT
 SUBT	 OPT	 PROG	 SEARCH
 PROG	 SEARCH	 PICTURE	 ECO
 SEARCH	 PICTURE	 SLEEP	 TV/R
 SLEEP	 TV/R	 FORMAT	 3D
 FORMAT	 3D	 E-MANUAL	 REPEAT
 E-MANUAL	 REPEAT	 ZOOM	 TIMER
 ZOOM	 TIMER	 D.MENU	 TEXT
 D.MENU	 TEXT	 ▲	 AV
 ▲	 AV	 TOP MENU/MENU	 DISPLAY/INFO
 TOP MENU/MENU	 DISPLAY/INFO	 OK	 OK
 OK	 OK	 CLEAR/EXIT	 RETURN/BACK
 CLEAR/EXIT	 RETURN/BACK	 HOME	 SMART
 HOME	 SMART	 APP	 CH
 APP	 CH	 MEDIA	 MEDIA
 MEDIA	 MEDIA	 1	 2
 1	 2	 3	 4
 3	 4	 5	 6
 5	 6	 7	 8
 7	 8	 8	 9
 8	 9	 9	 FAV
 9	 FAV	 GUIDE	 PRE-CH
 GUIDE	 PRE-CH	 A	 B
 A	 B	 C	 D
 B	 C	 D	 D



