


















































































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Recall		Fav / Marker / PC
	Source		AV / Input / RDS		[i+]		Info / Angle
	TV		Shift + 1		AD		Sound / Title
	[<>]		Picture / Format		Vol+		Vol+
	3D		Shift + 3		Vol-		Vol-
	O)I/II		Audio / Lang I/II		Mute		Mute / Dimmer
	Subtitle		Subtitle / EQ		P+		CH+ / Page+
	1		1		P-		CH- / Page-
	2		2		Text		Text / Goto
	3		3		Quick		Display / Media
	4		4		List		Smart / List
	5		5		Menu		Menu / Home
	6		6		Guide		Guide / EPG / -/-
	7		7		[.]		D.Menu / Top
	8		8		[>]		Setup / OPT /
	9		9		Exit		Exit / Cancel / Clear
	0		0		Up		Up





Originale	Sostituto	Originale	Sostituto
	Down		Down
	Right		Right
	Left		Left
	Back		Back / Return
	OK		OK
	>>		Shift + Right
	Play		Play / Slow
	<<		Shift + Left
	Stop		Stop / Hold
	Pause/Step		Pause / Step / Freeze
	↑↑		Shift + Up
	↓↓		Shift + Down
	Rec		Rec / Rec Mode
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	<</[≡+]		<< / Tune-
	Blue		Blue / Prime Video / Random
	>>/[≡◇]		>> / Tune+
	<</[≡?]		<< / Preset-
	>> /[O]/[≡x]		>>  / Preset+
	[▽]		TV/Radio /

