

































































































Originale	Sostituto
 Standby	 Power
 Open/Close	 Eject
 Input Select	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Prog+	 Ch +
 Prog-	 Ch -
 Clear	 Exit
 Mode	 Format

Originale	Sostituto
 Zoom	 Shift + Eject
 OO/Audio	 Dual
 Search	 TV/R
 Repeat	 Text
 Top Menu	 Menu
 Disc Menu	 D. Menu
 Enter	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Return	 Back
 Display	 Info
 Instant Skip	 Guide
 1.3x/0.8x Play	 Subt
 Time Slip	 Sleep
 Play	 Play





Originale	Sostituto	Originale	Sostituto
 Stop	 Stop		
 Pause	 Pause		
 <<	 <<		
 >>	 >>		
 >>	 >>		
  <<	  <<		
 Rec	 Rec		
 DVD	 Green		
 VCR	 Red		
 Dubbing	 Blue		
 Sat Link	 Media		
 Timer Set	 3D		
 Timer Prog.	 List		
 Rec Mode	 Shift + Rec		
 Setup	 Options		

