




































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Home	 Smart
 Input	 AV	 P+	 Ch +
 Mute	 Mute	 P-	 Ch -
 1	 1	 [i+]	 Info
 2	 2	 Guide	 Guide
 3	 3	 Back	 Back
 4	 4	 Exit	 Exit
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 OK	 Ok
 0	 0	 Red	 Red
 Lang	 Dual	 Green	 Green
 TXT	 Text	 Yellow	 Yellow
 Vol+	 Vol +	 Blue	 Blue
 Vol-	 Vol -	 Prime Video	 Shift + Smart

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Home	 Smart
 Input	 AV	 P+	 Ch +
 Mute	 Mute	 P-	 Ch -
 1	 1	 [i+]	 Info
 2	 2	 Guide	 Guide
 3	 3	 Back	 Back
 4	 4	 Exit	 Exit
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 OK	 Ok
 0	 0	 Red	 Red
 Lang	 Dual	 Green	 Green
 TXT	 Text	 Yellow	 Yellow
 Vol+	 Vol +	 Blue	 Blue
 Vol-	 Vol -	 Prime Video	 Shift + Smart





	Originale	Sostituto	Originale	Sostituto
	Netflix	 Media		
	You Tube	 Shift + Media		
	<<	 <<		
	Pause	 Pause		
	>>	 >>		
	Rec	 Rec		
	Play	 Play		
	Stop	 Stop		

