



Originale	Sostituto	Originale	Sostituto
Power	Power	Vol+	Vol +
Input	AV	Vol-	Vol -
1	1	Mute	Mute
2	2	[i+]	Info
3	3	Guide	Guide
4	4	Back	Back
5	5	Exit	Exit
6	6	Up	Up
7	7	Down	Down
8	8	Right	Right
9	9	Left	Left
0	0	OK	Ok
Lang	Dual	Red	Red
TXT	Text	Green	Green
P+	Ch +	Yellow	Yellow
P-	Ch -	Blue	Blue
Home	Smart	Prime Video	Shift + Smart

Originale	Sostituto	Originale	Sostituto
Vol+	Vol +	Mute	Mute
Vol-	Vol -	[i+]	Info
Mute	Mute	Guide	Guide
[i+]	Info	Back	Back
Guide	Guide	Exit	Exit
Back	Back	Up	Up
Exit	Exit	Down	Down
Up	Up	Right	Right
Down	Down	Left	Left
Right	Right	OK	Ok
Left	Left	Red	Red
OK	Ok	Green	Green
Red	Red	Yellow	Yellow
Green	Green	Blue	Blue
Yellow	Yellow	Prime Video	Shift + Smart
Blue	Blue		



