







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		FAV		Shift + Pre Ch
	Input		AV		Vol+		Vol +
	Sleep		Sleep		Vol-		Vol -
	Freeze		Shift + Pause		Recall		Pre Ch
	Pic Mode		Format		Mute		Mute
	Pic Size		3D		C.Caption		Smart
	1		1		CH+		Ch +
	2		2		CH-		Ch -
	3		3		CH RTN		Back
	4		4		Info		Info
	5		5		Up		Up
	6		6		Left / Back CB		Left
	7		7		Enter		Ok
	8		8		Right / Next CB		Right
	9		9		Down		Down
	0		0		Menu		Menu
	100		Guide		Exit		Exit



