









































| Originale  | Sostituto   |
|--|---|
|  Power        |  Power   |
|  Open / Close |  Eject   |
|  Input Select |  AV      |
|  HDMI         |  Media   |
|  1            |  1       |
|  2            |  2       |
|  3            |  3       |
|  4            |  4       |
|  5            |  5       |
|  6            |  6       |
|  7           |  7      |
|  8          |  8     |
|  9          |  9     |
|  0          |  0     |
|  SAT Link   |  Smart |
|  Clear      |  Exit  |
|  Prog+      |  Ch +  |

| Originale   | Sostituto  |
|---|--|
|  Prog-     |  Ch -           |
|  Time Slip |  Sleep          |
|  Info      |  Info           |
|  Text      |  Text           |
|  Audio     |  Dual           |
|  Subtitle  |  Subt           |
|  Guide     |  Guide          |
|  Top Menu  |  Menu           |
|  Disc Menu |  D. Menu        |
|  Up        |  Up             |
|  Left     |  Left          |
|  Enter   |  Ok           |
|  Right   |  Right        |
|  Down    |  Down         |
|  Display |  Shift + Info |
|  Return  |  Back         |
|  Red     |  Red          |



