







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Exit/Back	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [◀▶]	 PICTURE FORMAT
 0	 0	 → ◻ ←	 SEARCH TV/R
 Recall	 FAV PRE-CH	 [i+] / [≡i]	 DISPLAY INFO
 Source	 TIMER AV	 Text / [≡] / [≡] [ ]	 REPEAT TEXT
 Menu/DVD	 TOP MENU MENU	 [  ] / [▼]	 [  ]
 Guide	 -/-- GUIDE	 [▶] / [I/II]	 PLAY MODE ▶
 [■][■■][■■■]	 ECO 3D	 [▶] / [I/II]	 SOUND DUAL























Originale	Sostituto	Originale	Sostituto
<< / [=○]	<<		
<< / [=○]	Options		
>> / Subtitle	Subt		
>> / Subtitle	>>		
▲	Smart		
■ / [=□]	Stop		
■◀◀ / [=⇕]	Eject		
■◀◀ / [=⇕]	I<<		
▶▶ / [=X]	>>I		
▶▶ / [=X]	Back		
	A Red		
	B Green		
	C Yellow		
	D Blue		































































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 _ Menu/DVD	 Menu
 - Exit/Back	 Exit
 - Up	 Up
 Left	 Left
 OK	 Ok

Originale	Sostituto
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
  / [v]	 Pause
  / I/II	 Play
  / I/II	 Dual
  / [≡●]	 <<<
  / [≡●]	 TV/R
  / Subtitle	 >>>
  / Subtitle	 Subt
  ▲	 Smart
  / [≡□]	 Stop
  / [≡⇅]	 Eject
  / [≡⇅]	 I<<<
  / [⊙][≡X]	 >>>I
  / [⊙][≡X]	 Back





Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Mute	 Mute
 1	 1	 2	 2
 3	 3	 4	 4
 5	 5	 6	 6
 7	 7	 8	 8
 9	 9	 0	 0
 Source	 AV	 P+	 Ch +
 P-	 Ch -	 Vol-	 Vol -
 Vol+	 Vol +		

Originale	Sostituto	Originale	Sostituto
 Pause	 Pause	 Play	 Play
 Fast Forward	 Dual	 Fast Reverse	 <<<
 Stop	 TV/R	 Subtitle	 >>>
 Subtitle	 Subt	 Home	 Smart
 Stop	 Smart	 Eject	 Eject
 Eject	 Eject	 Back	 Back
 [X]	 Back	 [X]	 >>>

