



Originale	Sostituto
Power	Power
Sleep	Sleep
1 HDMI	1
2 HDMI	2
3 HDMI	3
4 HDMI	4
1 AV	5
2 AV	6
3 AV	7
4 AV	8
5 AV	9
1 Audio	Guide
2 Audio	0
V-AUX	AV
Tuner	Pre Ch
FM Tuner	Smart
AM Tuner	Media

Originale	Sostituto
Memory	D. Menu
Preset Tuner Up	Shift + Up
Preset Tuner	Shift + Down
Tuning Up	Ch +
Tuning Down	Ch -
Info	Info
Movie	I<<
Surr.Decode	>>I
Music	<<
Straight	Play
Stereo/Enhance	>>
BD/DVD	Red
TV	Green
CD	Yellow
Radio	Blue
Return	Back
Setup	Menu





Originale		Sostituto		Originale		Sostituto	
	Option		Options				
	Up		Up				
	Down		Down				
	Right		Right				
	Left		Left				
	Enter		Ok				
	Vol+		Vol +				
	Vol-		Vol -				
	Mute		Mute				

