



Originale	Sostituto
 Power	 Power
 Sleep	 Sleep
 CD	 1
 iPod	 2
 AUX	 3
 Tuner	 4
 USB	 6
 Folder Down	 Ch -
 Folder Up	 Ch +
 ←	 <<
 →	 >>
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Menu	 Menu

Originale	Sostituto
 Play	 Play
 Pause	 Pause
 >>I	 >>I
 I<<	 I<<
 Stop	 Stop
 Option	 Options
 Back	 Back
 X	 Media
 Display	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 << Tuning	 Red
 Tuning >>	 Green
 < Preset	 Yellow
 Memory	 TV/R
 Preset >	 Blue

