

































































| Originale | Sostituto |
|---|----------------------------|
|  | Power |
|  | Mute |
|  | Nicam/A2 |
|  | Aspect |
|  | P.Mode |
|  | S.Mode |
|  | 1 |
|  | 2 |
|  | 3 |
|  | 4 |
|  | 5 |
|  | 6 |
|  | 7 |
|  | 8 |
|  | 9 |
|  | 0 |
|  | Shift + Audio / Lang I/II |
|  | Shift + Picture / Format |
|  | Picture / Format |
| | Sound / Title |
| | 1 |
| | 2 |
| | 3 |
| | 4 |
| | 5 |
| | 6 |
| | 7 |
| | 8 |
| | 9 |
| | Shift + Guide / EPG / -/-- |
| | 0 |

| Originale | Sostituto |
|---|-----------------------------|
|  | Recall |
|  | Display |
|  | Freeze |
|  | Rec/Auto |
|  | Red / Netflix / Search |
|  | Green / APP / Repeat |
|  | Yellow / YouTube / Repeat |
|  | Blue / Prime Video / Random |
|  | Sleep / Timer |
|  | Up |
|  | Source |
|  | Left |
|  | Enter |
|  | Right |
|  | Down |
|  | Menu |
|  | Exit |
|  | Back / Return |
|  | Display / Media |
|  | Pause / Step / Freeze |
|  | Rec / Rec Mode |
|  | Red / Netflix / Search |
|  | Green / APP / Repeat |
|  | Yellow / YouTube / Repeat |
|  | Blue / Prime Video / Random |
|  | Sleep / Timer |
|  | Up |
|  | AV / Input / RDS |
|  | Left |
|  | OK |
|  | Right |
|  | Down |
|  | Menu / Home |
|  | Exit / Cancel / Clear |





| Originale | | Sostituto | | Originale | | Sostituto | |
|---|-----------------|---|-------------------|---|----------|---|-------------------|
|  | CH+ |  | CH+ / Page+ |  | DTV |  | Smart / List |
|  | Subtitle |  | Subtitle / EQ |  | EPG |  | Guide / EPG / -/- |
|  | Vol+ |  | Vol+ |  | Tv/Radio |  | TV/Radio / |
|  | CH- |  | CH- / Page- | | | | |
|  | T.Shift |  | Setup / OPT / | | | | |
|  | Vol- |  | Vol- | | | | |
|  | Play/Pause/Hold |  | Play / Slow | | | | |
|  | Play/Pause/Hold |  | Shift + Stop / | | | | |
|  | <</Reveal |  | << / Tune- | | | | |
|  | >>/Size |  | Zoom / Size | | | | |
|  | >>/Size |  | >> / Tune+ | | | | |
|  | Stop/Index |  | Stop / Hold | | | | |
|  | I<< |  | I<< / Preset- | | | | |
|  | S.Page/>>I |  | >>I / Preset+ | | | | |
|  | Text |  | Text / Goto | | | | |
|  | FAV |  | Fav / Marker / PC | | | | |
|  | Audio |  | Audio / Lang I/II | | | | |

