





























































Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/0	 Shift + Guide / EPG / -/0
 0	 0
 Recall	 Back / Return
 Vol +	 Vol+
 Aspect	 Shift + Picture / Format
 Nicam	 Audio / Lang I/II

Originale	Sostituto
 CH +	 CH+ / Page+
 Vol -	 Vol-
 Input	 AV / Input / RDS
 CH -	 CH- / Page-
 Up	 Up
 Left	 Left
 Enter	 OK
 Right	 Right
 Menu	 Menu / Home
 Down	 Down
 Exit	 Exit / Cancel / Clear
 Display	 Display / Media
 PMode	 Picture / Format
 S.Mode	 Sound / Title
 Sleep	 Sleep / Timer
 FAV	 Fav / Marker / PC
 FAV -	 Shift + Down





Originale	Sostituto
FAV+	FAV +  +  Shift + Up
EPG	 Guide / EPG / -/--
TEXT	 Text / Goto
HOLD	 +  Shift + Stop /
LANG	 +  Shift + Audio / Lang I/II
SUBTITLE	 Subtitle / EQ
INDEX / <<	 << / Tune-
INDEX / <<<	 Info / Angle
SIZE / >>	 >> / Tune+
SIZE / >>>	 Zoom / Size
REVEAL / I<<	 I<< / Preset-
Subpage / >>I	 >>I / Preset+
Subpage / >>I	 Eject / Surround
Rec	 Rec / Rec Mode
Play / Pause	 Play / Slow
Play / Pause	 Pause / Step / Freeze
Stop	 Stop / Hold

Originale	Sostituto
MEDIA	 +  Shift + Display / Media
TV/RADIO	 TV/Radio /
TV/RADIO	 Red / Netflix / Search
Green	 Green / APP / Repeat
Yellow	 Yellow / YouTube / Repeat
Blue	 Blue / Prime Video / Random

