



























































Originale	Sostituto
 Power	 Power
 Menu	 Menu
 Exit	 Exit
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 Audio / I/II	 Dual
 Red	 Red

Originale	Sostituto
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue
 Q.Menu	 D. Menu
 Back	 Back
 Up	 Up
 Right	 Right
 Down	 Down
 Left	 Left
 OK	 Ok
 EPG	 Guide
 YouTube	 Media
 Vol +	 Vol +
 Vol -	 Vol -
 Source	 AV
 Text	 Text
 P +	 Ch +







































Originale		Sostituto		Originale		Sostituto	
	P -		Ch -				
	List		List				
	Netflix		Smart				
	Play		Play				
	Pause		Pause				
	Stop		Stop				
	Rec		Rec				
	<<		<<				
	<<		<<				
	>>		>>				
	>>		>>				





Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Play	 Play
 Pause / Mix	 Pause
 Pause / Mix	 Shift + Text
 Stop / Hold	 Stop
 Size	 Format
 << / Timer	 <<
 << / Timer	 Shift + Power
 I<< / Index	 I<<
 >>I / Reveal	 >>I
 >> / Cancel	 >>
 >> / Cancel	 Shift + Exit
 Info	 Info
 Audio / I/II	 Dual
 Text	 Text
 Back / Del	 Back

Originale	Sostituto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Settings	 Options
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down



