







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		prime video		Shift + Media
	Smart		Smart		Home		Shift + Smart
	1		1		Menu		Menu
	2		2		Back		Back
	3		3		Exit		Exit
	4		4		Up		Up
	5		5		Down		Down
	6		6		Right		Right
	7		7		Left		Left
	8		8		OK		Ok
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	Info		Info		Mute		Mute
	Guide		Guide		CH+		Ch +
	Netflix		Media		CH-		Ch -
	YouTube		Options		Source		AV
	Google Play		3D		Red		Red





Originale		Sostituto		Originale		Sostituto	
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	<<		<<				
	Play		Play				
	>>		>>				
	Rec		Rec				
	Pause		Pause				
	Stop		Stop				
	Text		Text				
	Subt		Subt				
	Audio		Dual				

