Mandis shop

Technics RAKCH426WH

Originale		Sostituto	
POWER	Power		Power
CD/ TAPE	CD/Tape	HOME SMART	Smart
TUNER/ BAND	Tuner/Band	APP MEDIA	Media
DECK 1/2 1	1/Deck 1/2	1	1
2	2/<<	2	2
3	3/>>	3	3
4	4/< Tape	4	4
5	5/Stop Tape	5	5
6	6/Tape >	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
≥10	+10	-/-- GUIDE	Guide
PROGRAM	Program	TOP MENU MENU	Menu
CD	Play CD	PLAY MODE	Play
CD	Stop CD		Stop

Originale		Sostituto	
CANCEL	Cancel	CLEAR EXIT	Exit
I<</<<	I<</<<		<<
>>/>>I	>>/>>I		>>
EQ SPACE	EQ Space	SETTINGS OPT	Options
SLEEP	Sleep	PROG SLEEP	Sleep
MUTING	Muting	MUTE	Mute
UME +	Vol+	+ VOL	Vol +
– VOL	Vol-	VOL –	Vol -

https://tutti-i-telecomandi.it/it/Technics/1055444-23873-telecomando-di-sostituzione-per-Technics-RAK-CH426WH.html