Originale	Sostituto	Originale	Sostituto
Power	Power	Sleep	Sleep
CD Direct 1	1	Vol +	Vol +
CD Direct 2	2	Vol -	Vol -
CD Direct 3	3		
Pause	Pause		
Play	Play		
Stop	Stop		
>>	>>		
<<	<<		
>I	>>I		
I<	I<<		
Mute	Mute		
DSC	Guide		
DBB	Pre Ch		
Repeat	Text		
Shuffle	3D		
DIM	Media		

Originale		Sostituto	
	Power		Power
DIM	DIM	APP MEDIA	Media
SLEEP	Sleep	PROG SLEEP	Sleep
1	CD Direct 1	1	1
2	CD Direct 2	2	2
3	CD Direct 3	3	3
	Pause		Pause
	Play	PLAY MODE	Play
	>I		>>I
	I<		I<<
	Stop		Stop
MUTE	Mute	MUTE	Mute
DSC	DSC	-/-- GUIDE	Guide
DBB	DBB	FAV PRE-CH	Pre Ch
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	<<		<<

Originale		Sostituto	
	>>		>>

Originale	Sostituto	Originale	Sostituto
Power	Power		
DIM	Media		
Sleep	Sleep		
CD Direct 1	1		
CD Direct 2	2		
CD Direct 3	3		
Vol +	Vol +		
Vol -	Vol -		
>I	>>I		
I<	I<<		
>>	>>		
<<	<<		
Mute	Mute		
DSC	Guide		
DBB	Pre Ch		

Originale	Sostituto	Originale	Sostituto
Power	Power		
DIM	Media		
Sleep	Sleep		
CD Direct 1	1		
CD Direct 2	2		
CD Direct 3	3		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
DSC	Guide		
DBB	Pre Ch		