Mandis shop

Aiwa RM-Z20051

Originale		Sostituto	
I / ⏻	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DISPLAY	Display	DISPLAY INFO	Info
SELECT	Clock Timer	-/-- GUIDE	Guide
SET	Clock Timer Set	SETTINGS OPT	Options
TUNER MEMORY	Tuner Memory	ECO 3D	3D
PLAY MODE/ TUNING MODE	Play Mode/Tuning Mode	SEARCH TV/R	TV/R
REPEAT/ FM MODE	Repeat/FM	REPEAT TEXT	Text
TAPE	Tape	A	Red
TUNER BAND	Band/Tuner	B	Green
CD	CD	C	Yellow
FUNCTION	Function	TOP MENU MENU	Menu
+	>>I/+		>>I
–	I<</-		I<<
	>>		>>
	<<		<<
	Play	PLAY MODE	Play

Originale		Sostituto	
	Pause		Pause
	Stop		Stop
CLEAR	Clear	CLEAR EXIT	Exit
ENTER	Enter	OK	Ok
EQ	EQ	SOUND DUAL	Dual
DISC SKIP	Disc Skip	DISC NAV LIST	List
+ VOLUME	Vol+	+ VOL	Vol +
VOLUME –	Vol-	VOL –	Vol -
+ ALBUM	Album+	+ CH	Ch +
– ALBUM	Album-	CH –	Ch -

https://tutti-i-telecomandi.it/it/1056842-8767-telecomando-di-sostituzione-per-Aiwa-RMZ20051-147852011.html