Mandis shop

Grundig RP100

Originale		Sostituto	
STANDBY	Standby		Power
CASS.	Cass		Audio
TIMER	Timer		Subt.
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+	+	CH +	CH +
-	-	CH -	CH -
SEL/VPS	SEL/VPS	EPG	-/-- / EPG
CLEAR	Clear	FAV	P/C / FAV

Originale		Sostituto	
RECORD/OTR	Record/OTR		Rec
STILL	Still	VOD	VOD
<<	<<		Rewind
>>	>>		Fast Forward
PLAY	Play		Play
PREVIOUS	Previous		First
NEXT	Next		Last
PAUSE/STOP	Pause		Pause
PAUSE/STOP	Stop		Stop
MONITOR	Monitor	SRC	SRC
TUNER	Tuner	TV/R	TV/R
TRACKING	Tracking	OPT+	OPT+
SP/LP	SP/LP	MEDIA	MEDIA