Mandis shop

RC-1000C

Originale	Sostituto	Originale	Sostituto
Line 1	Power		
Line2	Mute / Dimmer		
Balanced	Play / Slow		
Tape1	Pause / Step / Freeze		
Tape 2	Stop / Hold		
Phono	Rec / Rec Mode		
Source Direct On/Off	<< / Tune-		

https://tutti-i-telecomandi.it/it/Kenwood/1066924-93672-telecomando-di-sostituzione-per-Kenwood-RC-1000C.html